

EaseRoll

MW-ST-T-184-185



Installation instruction


Web: www.mwworkstation.com

Tel: +86 13695211636


Mail: robbor@mwworkstation.com

CONTENTS

01 without table




02 with table



EaseRoll without table


PARTS SHOW

A




[chair back]

B



[Seat cushions and legs]

C



4 PCS

[wheel]

D




L/R

1 SET

[connect]

1



M6*20mm

4 PCS

[screw]

2




4mm


[equipment]

INSTALLATION STEPS


1



2




3



EaseRoll with table


PARTS SHOW

A




[chair back]

B



[Seat cushions and legs]

C



4 PCS

[wheel]


D



L/R

[connect]

E



[small table]


1



M6*20mm

[screw]


2



[equipment]


INSTALLATION STEPS

1




[Install wheels]

2



[Install connectors and seat back]

3



[finish installation]



Web: mwworkstation.com

Mail: robbor@mwworkstation.com

Tel: +86 13695211636

WhatsApp: + 86 13695211636

Add: NO.3 Xingye North Road Dawotang Industrial
District Shishan Nanhai Foshan City Guangdong
P.R China



WhatsApp



Facebook



Instagram



Twitter



Pinterest



Linkein



YouTube