

SEG

Training Table

MW-DT-N-207-211



Installation instruction

Web: www.mwworkstation.com

Tel: +86 13695211636

Mail: robbor@mwworkstation.com

Training Table


PARTS SHOW

A



Upper support

B



Foot joint


Foot joint cover

C



Foot tube

D




Cross beam

E



Bottom foot

F



Plastic baffle

PARTS SHOW

G



Connecting screws

H



Casters

I



Wrench

INSTALLATION STEPS

